M12 Field Attachable Connectors

RSC



M12 male connector

Field attachable connector, M12 male connector with threaded joint, 3-8 poles, assembling with screw terminals

Туре
RSC 3/7
RSC 3/9
RSC 4/7
RSC 4/9
RSC 5/7
RSC 5/9
RSC 8/9

RSCW



M12 male connector, angled

Field attachable connector, M12 male right angle connector with threaded joint, 3–8 poles, assembling with screw terminals

Туре
RSCW 3/7
RSCW 3/9
RSCW 4/7
RSCW 4/9
RSCW 5/7
RSCW 5/9
RSCW 8/9

RKC



M12 female connector

Field attachable connector, M12 female connector with threaded joint, $3\!-\!8$ poles, assembling with screw terminals

Туре
RKC 4/3/7
RKC 4/3/9
RKC 4/7
RKC 4/9
RKC 5/7
RKC 5/9
RKC 8/9

RKCW



M12 female connector, angled

Field attachable connector, M12 female right angle connector with threaded joint, 3-8 poles, assembling with screw terminals

Туре
RKCW 4/3/7
RKCW 4/3/9
RKCW 4/7
RKCW 4/9
RKCW 5/7
RKCW 5/9
RKCW 8/9

RSCS



M12 male connector

Field attachable connector, M12 male connector with threaded joint, $4\!-\!8$ poles, shieldable, assembling with screw terminals

Туре	
RSCS 4/9	
RSCS 5/9	
BSCS 8/9	

RKC



M12 female connector

Field attachable connector, M12 female connector with threaded joint, shieldable, assembling with screw terminals

Туре	
RKCS 4/9	
RKCS 5/9	
RKCS 8/9	

M12 Receptacle Connectors

RSFM.../0.5 M



M12 male connector

Receptacle connector, M12 male connector for front mounting, assembled stranded wire, solder contacts potted with epoxy, chassis side thread M16 x1.5 (panel nut RSKFM 16)

Туре
RSFM 3/0.5 M
RSFM 4/0.5 M
RSFM 5/0.5 M
RSFM 8/0.5 M

RSHL.../S 5,5



M12 male connector

Receptacle connector, M12 male connector for rear mounting, print contacts, chassis side thread PG 9 (panel nut RSKF 9)

1	Гуре
F	RSHL 4/S 5,5
F	RSHL 5/S 5,5
F	RSHL 8/S 5,5

RKFM.../0.5 M



M12 female connector

Receptacle connector, M12 female connector for front mounting, assembled stranded wire, solder contacts potted with epoxy, chassis side thread M16x1.5 (panel nut RSKFM 16)

Туре
RKFM 4-3/0.5 M
RKFM 4/0.5 M
RKFM 5/0.5 M
RKFM 8/0.5 M

RKHL.../S 5,5



M12 female connector

Receptacle connector, M12 female connector for rear mounting, printed contacts, chassis side thread PG 9 (panel nut RSKF 9)

Туре	
RKHL 4/S 5,5	
RKHL 5/S 5,5	
RKHI 8/S 5 5	

M12 Cordsets, Single-ended

RST



M12 male connector

Outer jacket material: 06 | 07 | 56 = PVC, orange 224 | 225 | 228 = PUR halogen-free, black 344 | 346

Type RST 3-06/2 M RST 3-06/5 M RST 3-06/10 M RST 3-224/2 M RST 3-224/5 M RST 3-224/10 M RST 4-07/2 M RST 4-07/5 M RST 4-07/10 M RST 4-225/2 M RST 4-225/5 M RST 4-225/10 M RST 5-56/2 M RST 5-56/5 M RST 5-56/10 M RST 5-228/2 M RST 5-228/5 M RST 5-228/10 M RST 8-344/2 M RST 8-344/5 M RST 8-344/10 M RST 12-346/2 M RST 12-346/5 M RST 12-346/10 M

RKT



M12 female connector

Outer jacket material: 06 | 07 | 56 = PVC, orange 224 | 225 | 228 = PUR halogen-free, black 344 | 346

RKT 4-3-06/2 M RKT 4-3-06/5 M RKT 4-3-06/10 M RKT 4-3-224/2 M RKT 4-3-224/5 M RKT 4-3-224/10 M RKT 4-07/2 M RKT 4-07/5 M RKT 4-07/10 M RKT 4-225/2 M RKT 4-225/5 M RKT 4-225/10 M RKT 5-56/2 M RKT 5-56/5 M RKT 5-56/10 M RKT 5-228/2 M RKT 5-228/5 M RKT 5-228/10 M RKT 8-344/2 M RKT 8-344/5 M RKT 8-344/10 M RKT 12-346/ 2 M RKT 12-346/ 5 M RKT 12-346/10 M

Type

M12 Cordsets, Single-ended

RSWT



M12 male connector, angled

Outer jacket material: 06 | 07 | 56 = 224 | 225 | 228 = = PVC, orange

= PUR halogen-free, black

туре
RSWT 3-06/2 M
RSWT 3-06/5 M
RSWT 3-06/10 M
RSWT 3-224/2 M
RSWT 3-224/5 M
RSWT 3-224/10 M
RSWT 4-07/2 M
RSWT 4-07/5 M
RSWT 4-07/10 M
RSWT 4-225/2 M
RSWT 4-225/5 M
RSWT 4-225/10 M
RSWT 5-56/2 M
RSWT 5-56/5 M
RSWT 5-56/10 M
RSWT 5-228/2 M
RSWT 5-228/5 M
RSWT 5-228/10 M

RKWT



M12 female connector, angled

= PVC, orange

Outer jacket material: 06 | 07 | 56 = 224 | 225 | 228 = = PUR halogen-free, black

Ty	уре
R	KWT 4-3-06/2 M
R	KWT 4-3-06/5 M
R	KWT 4-3-06/10 M
R	KWT 4-3-224/2 M
R	KWT 4-3-224/5 M
R	KWT 4-3-224/10 M
R	KWT 4-07/2 M
R	KWT 4-07/5 M
R	KWT 4-07/10 M
R	KWT 4-225/2 M
R	KWT 4-225/5 M
R	KWT 4-225/10 M
RI	KWT 5-56/2 M
RI	KWT 5-56/5 M
RI	KWT 5-56/10 M
RI	KWT 5-228/2 M
RI	KWT 5-228/5 M
RI	KWT 5-228/10 M

M12 Cordsets, Single-ended

RSTS



M12 male connector with shielding

Outer jacket material: 182 | 183 | 184 288 | 298 | 299 = PVC, orange = PUR halogen-free, black

туре
RSTS 4-182/2 M
RSTS 4-182/5 M
RSTS 4-182/10 M
RSTS 4-288/2 M
RSTS 4-288/5 M
RSTS 4-288/10 M
RSTS 5-183/2 M
RSTS 5-183/5 M
RSTS 5-183/10 M
RSTS 5-298/2 M
RSTS 5-298/5 M
RSTS 5-298/10 M
RSTS 8-184/2 M
RSTS 8-184/5 M
RSTS 8-184/10 M
RSTS 8-299/2 M
RSTS 8-299/5 M
RSTS 8-299/10 M

RKTS



M12 female connector with shielding

Outer jacket material:

182 | 183 | 184 288 | 298 | 299

= PVC, orange = PUR halogen-free, black

Туре
RKTS 4-182/2 M
RKTS 4-182/5 M
RKTS 4-182/10 M
RKTS 4-288/2 M
RKTS 4-288/5 M
RKTS 4-288/10 M
RKTS 5-183/2 M
RKTS 5-183/5 M
RKTS 5-183/10 M
RKTS 5-298/2 M
RKTS 5-298/5 M
RKTS 5-298/10 M
RKTS 8-184/2 M
RKTS 8-184/5 M
RKTS 8-184/10 M
RKTS 8-299/2 M
RKTS 8-299/5 M
RKTS 8-299/10 M

M12 Cordsets, Single-ended

RKWTS



M12 female connector with shielding, angled

Outer jacket material: 182 | 183 | 184 | 298 | 299

= PVC, orange = PUR halogen-free, black

Туре
RKWTS 4-182/2 M
RKWTS 4-182/5 M
RKWTS 4-182/10 M
RKWTS 4-288/2 M
RKWTS 4-288/5 M
RKWTS 4-288/10 M
RKWTS 5-183/2 M
RKWTS 5-183/5 M
RKWTS 5-183/10 M
RKWTS 5-298/2 M
RKWTS 5-298/5 M
RKWTS 5-298/10 M
RKWTS 8-184/2 M
RKWTS 8-184/5 M
RKWTS 8-184/10 M
RKWTS 8-299/2 M
RKWTS 8-299/5 M
RKWTS 8-299/10 M

M12 Accessories



Dust cover for unused M12 sockets

Type

ZVK

0909 UAC 101



Dust cover for unused M12 male connectors

Type 0909 UAC 101

RSKF 9 | RSKFM 16 | RSKFM 20



Panel nut for M12 male and female receptacles

RSKF 9: PG 9 RSKFM 16: M16x1.5 RSKFM 20: M20x1.5

Type RSKF 9 RSKFM 16 RSKFM 20